

### 3 OPERATION

This chapter has the same contents of the corresponding chapter of the probe manual with the exception of the record format sent after the receiving of the command A.

#### Record Format:

```
SA8000- 01 4.5 09/11/99 16:35:25 ±300.00m ±20.00°C ±40.000mS ±
.....+.....|.....+.....|.....+.....|.....+.....|.....+.....|.....+.....|.....+.....|
12.000pH ±1000.0mV ±100.00%air ±4000.0NTU 09/11/99xx
```

SA8000: P/N of the probe  
 01: ID of the probe  
 4.5: voltage of the power supply  
 09/11/99: date (only for models SA8060.x0x with data logger)  
 16:35:25: time (only for models SA8060.x0x with data logger)



## 1 DESCRIPTION

The option 091.181 will add the turbidity measuring to the multiparameter probes SA8060.x0x and SA8065.x0x series.

Level, temperature, electric conductivity, pH, ORP and dissolved oxygen measuring will remain the same.

This manual is an integration of the regular Manual of the probe.

NOTE



